

## **CEVOL PRODUCT USER MANUAL BM.1FC STILLAGE**

### **STILLAGE DESCRIPTION**

BULK COLLAPSIBLE STILLAGE. SHEET BASE, FOLDING FRAMES EACH END.

BASE DIMENSIONS: USABLE SPACE: OUTSIDE PALLET FEET: OVERALL HEIGHT: INSIDE HEIGHT: UNDER BASE: CUBIC CAPACITY: APPROXIMATE MASS PER UNIT: 2200 X 1061mm 2200 X 980mm 2292 X 1158mm 1285mm 1070mm 100mm 2.5 M3 163kg

## **DESIGN SPECIFICATIONS**

RATED CAPACITY (N.A.T.A) CERTIFIED: STACKING, FULLY LOADED: FORKING FULLY LOADED: TRUCKING FULLY LOADED: NET 1000kg PER UNIT 4 HIGH, STATIC FLAT 1 HIGH FROM ANY SIDE 1 HIGH

### STILLAGE ASSEMBLY

- **ENDS ASSY:** PULL EACH OF THE TWO FOLDING ENDS TO THEIR FULLY OPEN POSITIONS.
- **ENDS COLLAPSE:** PUSH POST KEEPER UP UNTIL IT CLEARS THE SHROUD. LOWER END DOWN TO BASE. DROPPING THE END REPEATEDLY WILL DAMAGE THE STILLAGE AND IS AN OH&S RISK TO THE OPERATORS.
- <u>CHECK ASSEMBLY</u>: MAKE SURE EACH POST KEEPER LOCATES FULLY. OVER THE SHROUD. PULLING THE END BACK AND FORTH WILL HELP THE POST KEEPER TO LOCATE FIRMLY.

### **Disclaimer – Important Notice**

The information contained in this document is provided to assist you in the operation of the product described above. Cevol Industries Pty Ltd does not accept any liability howsoever arising from injury or damage howsoever caused (whether fatal or otherwise) arising out of the use of this product in any way whatsoever due to any negligent act, breach of duty, default or omission or both, on the part of Cevol Industries Pty Ltd its directors, employees or agents.



# **CEVOL PRODUCT USER MANUAL BM.1FC STILLAGE**

## STILLAGE SAFETY ASSESSMENT

BEFORE USING ANY STILLAGE, THE OPERATOR MUST CHECK THAT:

- PALLET FEET ARE NOT BENT OR BROKEN.
- RACK RUNNERS ARE IN SAFE USABLE CONDITION.
- STILLAGE BASE IS IN GOOD CONDITION.
- POSTS ARE NOT DAMAGED AND THAT STILLAGE CAN BE STACKED OR STACKED ONTO.
- POST KEEPERS LOCATE FIRMLY.

### **STILLAGE DAMAGE & REPAIRS**

- DAMAGED STILLAGES SHOULD BE ASSESSED AND IF DEEMED TO BE UNSAFE, REMOVED FROM CIRCULATION.
- ANY TIME A STILLAGE IS REMOVED FROM CIRCULATION. IT SHOULD BE REPORTED TO THE RELEVANT SUPERVISOR.
- DAMAGED OR UNSAFE STILLAGES ARE TO BE RETURNED TO CEVOL INDUSTRIES FOR PROPER ASSESSMENT OR REPAIR.

### **GENERAL LOADING & TRUCKING OF STILLAGE**

- ALWAYS EVENLY DISTRIBUTE THE LOADING OF PRODUCT INTO THE STILLAGE AS BEST AS POSSIBLE.
- WHEN STACKING STILLAGES. MAKE SURE THE STILLAGE HAS INTERLOCKED PROPERLY, BEFORE REMOVING THE FORK LIFT.
- AVOID HAVING HEAVY LOADS ON TOP OF THE STACK.
- OPEN ENDED STILLAGE. RECOMMEND SECURING PRODUCT TO STILLAGE BEFORE TRANSPORTING.

OPERATORS ARE NOT TO EXCEED ANY OF THE DESIGN SPECIFICATIONS LISTED ABOVE. EACH STILLAGE HIRED OUT BY CEVOL INDUSTRIES IS IN A SAFE USABLE CONDITION, STENCILLED WITH THE MAXIMUM CAPACITY AND STACKING HEIGHT. OPERATORS ARE TO REPORT ANY DAMAGED STILLAGE TO THEIR SUPERVISOR FOR ASSESSMENT OR RETURN TO CEVOL INDUSTRIES.

#### **Disclaimer – Important Notice**

The information contained in this document is provided to assist you in the operation of the product described above. Cevol Industries Pty Ltd does not accept any liability howsoever arising from injury or damage howsoever caused (whether fatal or otherwise) arising out of the use of this product in any way whatsoever due to any negligent act, breach of duty, default or omission or both, on the part of Cevol Industries Pty Ltd its directors, employees or agents.